



1. In the address bar of the web browser of your choice, type in the **IP Address** of the copier
2. Make sure that **Public User** is checked
Note: you may not see this page only the next one
3. Click **Login**




4. Click **Store Address**




5. Click **New Registration**



6. Check **E-mail**
7. Click **OK**




8. Type **Name** to be displayed
9. Choose a rolodex tab for **address search**
10. Check **Main** if you want it on the first window for **FAX/SCAN** on the copier
11. Type in the **E-mail Address**
12. Click **OK**



13. Click **OK**

You will now see the e-mail address on the **Address Book List**



6. Check **Fax**
7. Click **OK**

KONICA MINOLTA Public To Login Screen

PAGE score Web Connection Model Name: bizhub C452

Address Book

- Store Address
- Icon
- Group
- Program
- Temporary One-Touch
- Subject
- Text

New Registration

- E-mail
- FTP
- SMB
- WebDAV
- User Box
- Fax

OK Cancel

8. Type **Name** to be displayed
9. Choose a rolodex tab for **address search**
10. Check **Main** if you want it on the first window for FAX/SCAN on the copier
11. Type in the **Destination**
12. Click **OK**

KONICA MINOLTA Public To Login Screen

PAGE score Web Connection Model Name: bizhub C452

Address Book

- Store Address
- Icon
- Group
- Program
- Temporary One-Touch
- Subject
- Text

Address Book (Fax)

No.

Use opening number
 Direct Input

Name

Index

Specify a keyword for address search and display by registered name.

DEF

Main

Destination Information

Destination
(one-byte numeric, #, *, ', ', 'T', 'P', 'E')

Communication Setting

Limiting Access to Destinations

OK Cancel

13. Click **OK**

You will now see the fax number on the **Address Book List**

No.:4 Address Book registration is complete.

OK